

maintenance of Salt pool system

Salt water pool system sets new standards for swimming pool and spas for its low running cost over the year. Since salt as compare to commercial chlorine are far more economical.

Salt pool systems delivers a constant stream of pure chlorine generated from salt. The benefits of such system replaces chloramines which are the source of irritations and the softening effects of electrolysis and reduction of dissolved alkali minerals offer soothing effects. For people who are sensitive to chlorine, the controlled amount of pure chlorine generated is less offensive.

The key to salt pool maintenance is simple but yet critical. Salt due to its corrosive properties must be controlled so it will not corrode the expensive electrolytic cells. The **SMART Pool Checker** is a simple yet effective tool to check for an ideal salt concentration so you do not overload the system.

SMART
Pool checker

Product Specification

	%	ppt
Range	0~1.00	0~10.0
Resolution	0.01%	0.1ppt
Accuracy	±0.02	±0.2

Order Code **SMART POOL CHECKER**



Key Features:

- Direct reading in % or ppt (parts-per-thousand)
- Rugged and water resistant
- Easy to use, just one press to read and readings are automatically locked with a stabilized endpoint reading with temperature compensation
- Simple maintenance with push button calibrations

While chlorine is generated through the electrolysis process, pH will rise as a result. A higher pH reduces the effectiveness of chlorine, it is also the cause for eye irritation. Therefore, balancing pH is necessary for proper sanitation and comfort. The **SMART Pool CheckPro** is a 3-in-1 meter that measures salt concentration, pH and temperature in one go, eliminating guesswork and simplify calculation of salt application and pH balance.

SMART
Pool checkPro

Key Features:

- Rugged and water resistant. Its length allows user to reach water level with ease
- Easy to use, just one press to read and readings are automatically locked with a stabilized endpoint reading with temperature compensation
- Simple maintenance with push button calibrations
- Uses 4 regular AA size battery which offers 50 hours of continuous use
- Economical 3-in-1 replacement sensor



Product Specification

	pH	%	ppt	Temp
Range	0~14.0	0~1.00	0~10.0	0~50
Resolution	0.1pH	0.01%	0.1ppt	0.1°C
Accuracy	±0.2	±0.02	±0.2	±0.5

Order Code

SMART POOL CHECKPRO